


ASSEMBLY GUIDE

PORTABLE 3-BURNER GAS GRIDDLE



Customer Service

📞 1-800-618-6798

FOR YOUR SAFETY!

Use outdoors only! Do not use it inside a building, garage, or any other enclosed space. Read the instructions before assembling and using the appliance.

DO NOT use the griddle unless it is completely assembled, and all the parts are securely fastened. This griddle will become very hot, do not move it during use. Keep away from children and pets.


CONTACT US FIRST!

This griddle has been made to high quality standards. If you have any questions that are not addressed in this Owner's Manual, or you need parts, please call our customer service hotline or send an email to service@royalgourmetusa.com. Please keep this Owner's Manual for future reference.






Learn more at:



www.royalgourmetcorp.com





• **Please note:** These parts are packed in a small box that is put under the firebox.


No.	#	QTY	Description	Image
1	W-10030015	4	Leg base	
2		1	Main body	
3	W-10030011	1	Grease cup	
4	GHJP23B-B	1	Cooking griddle	
5	W-GD430012	1	Regulator assembly	

Key	Description	QTY	Image
A	Stud with nut	2	
B	Stud	2	



Before beginning assembly, make sure all parts are present. If any parts are missing or damaged, do not attempt to assemble the products. Contact customer service for replacement parts via telephone or email.


• Approximate assembly time: 10 minutes

1




2

A		x2
B		x2




3



4

LP Cylinder Leak Test



Consider to manually light the burner with a lit match as shown if failing to light with piezo ignition.